

## Instruction Manual of the Transmitter

### How to **learn** the transmitters to the opener

Press and hold on “Code” button for 1 second until the LED dot is on. Press any one of the buttons on transmitter once, the dot will go off, press the same button again and the dot will flash fast for 8 times, and then return to standby mode.

The transmitter is now learnt into the opener. You can open/stop/close the door by this transmitter.

Repeat the above steps to learn more transmitters.

The opener has the capacity to store 20 transmitters.

If the led display flashes “F” and returns to standby mode (after you have pressed the “Code” button), this indicates that the memory storage is full (20 transmitters).



### How to **delete** all transmitters that are stored in the opener memory

Press and hold on “CODE” button for more than 8 seconds until the LED flashes “C”, all the stored codes are deleted.

Only the matched button on the transmitter is available.

If failed to match the transmitter within 20 seconds, then it will return to standby mode automatically.